

Section 12: Diagnostic Procedures

Engine Runs, but will not Change Speed

